

IMPORTANT SAFETY INSTRUCTIONS

When using electrical products, basic precautions should be always be followed including the following:

a) READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

- b) Do not use seasonal products unless marked suitable for indoor and outdoor use. When products are used in outdoor applications, connect the products to a Ground Fault Circuit Interrupting (GCFI) outlet. If one is not provided, contact a qualified electrician for proper installation.
- c) This seasonal product is not intended for permanent installation or use.
- d) Do not mount or place near gas or electric heater, fireplace, candles or othersimilar sources of heat.
- e) Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nail.
- f) Do not let lamps rest on the supply cord or on any wire.
- g) Unplug the product when leaving the house, when retiring for the night, or if left unattended.
- h) This is an electric product-not a toy! To avoid risk of fire, burns, personal injury and electric shock it should not be played with or placed where small children can reach it.
- i) Do not use this product for other than its intended use.
- j) Do not hang ornaments or other objects from cord wire, or light string.
- k) Do not close doors or windows on the product or extension cords as this may damage the wire insulation.
- l) Do not cover the product with cloth, paper or any material not part of the product when in use.
- m) The product is equipped with push-in type lamps. Do not twist lamps.
- n) This product employs overload protection (fuse). A brown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Also unplug any additional strings or products that may be attached to the product. Replace the fuse as per servicing instructions (follow product marking for proper fuse rating) and check the product. If the replacement fuse blows, a short-circuit may be present and the products should be discarded.
- o) Read and follow all instructions that are on the product or provide with the product.

p) SAVE THESE INSTRUCTIONS

Use and Care Instructions


- a) When the product is placed on a live tree, the tree should be well maintained and fresh. Do not place on live trees in which the needles are brown or break off easily. Keep the tree holder filled with water.
- b) If the product is placed on a tree, the tree should be well secured and stable.

- c) Before using or reusing, inspect product carefully. Discard any products that have cut, damaged, or frayed wire insulation or cords, cracks in the lampholders or enclosures, loose connections, or exposed copper wire.
- d) When storing the product, carefully remove the product from whenever it is placed, including tree, branches, or bushes, to avoid any undue strain or stress on the product conductors, connections, and wires.
- e) When not in use, store neatly in a cool, dry location protected from sunlight.

User Servicing Instructions


Replace the fuse

- a) Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
- b) Open fuse cover. Slide open fuse access cover on top of attachment plug towards blade.
- c) Remove fuse carefully.
- d) Risk of fire. Replace fuse only with 3 Amp, 125 Volt fuse (provided with product).
- e) Close fuse cover. Slide the fuse access cover on top of attachment plug.
- f) Risk of fire. Do not replace attachment plug. Contains a safety device (fuse) that should not be removed. Discard product if the attachment plug is damaged.



Replace the lamp

- 1. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
- 2. Pull lamp and plastic base straight out of lampholder.
- 3. Replace lamp with only 12 Volt, 0.96 Watt, super bright type lamp (provided with product).



If the new lamp base does not lit in lampholder, follow the steps before step 3.

- a) Remove the base of burned out lamp by straightening lamp leads and gently pull lamp out
- b) Thread leads of new lamp through holes in old base with one lead in each hole.
- c) After lamp is fully inserted into base, bend each lead up, like other lamps in the light set, so that the leads will touch the contacts inside the lampholder.

CAUTION

1. Risk of fire. The product does not contain lamp shunts, which allow the product to operate if one lamp burns out. Replace lamps only with the spare lamps provider with this product.

Model No.B6640RL