

ASSEMBLY INSTRUCTIONS

Roasting Fork Stand

For use with Roasting Forks Part# 4000416




BALSAM HILL®

NOTE:

To securely remove or attach the Stand to the Base, tighten or loosen the Set Screw located on the bottom of the Base with Allen key provided.

USE:

The Stand can be removed from its Base and be pressed into soft ground outdoors. To avoid rusting, avoid prolonged use outdoors. After use outdoors, wipe the bottom of the stand of debris before placing it back into the Base.



BH 4000417
PH 18715